

Diaphragm Vacuum Pump



MVP 020-3 DC

MVP 020-3 AC

Index

	Page		Page
1. Safety Precautions	2	6. Maintenance	11
1.1. For Your Orientation.....	3	6.1. Precautionary Measures During Maintenance Work	11
2. Understanding The Pump	4	6.2. Cleaning And Replacing Valves And Membranes.....	11
2.1. Main Features.....	4	7. Service	14
2.2. Differences Between The Pump Types.....	4	8. Technical Data	14
3. Installation	5	8.1. Dimensions.....	15
3.1. Setting Up The Pump And Location.....	5	8.2. Substances Which Come Into Contact With The Medium	16
3.2. Connecting The Vacuum Side.....	5	9. Spare Parts	16
3.3. Connecting The Exhaust Side.....	5	9. Accessories	17
3.4. Connecting To Mains Power.....	6	Contamination Declaration	18
3.4.1 Voltage Selector Switch Change-Over.....	6	Conformity Declaration	last page
3.4.2 Supply Connections of the MVP 020-3 DC.....	7		
4. Operations	8		
4.1. Important Information.....	8		
4.2. Setup of Control Signal Input.....	8		
4.2.1 Intermittent Operations with PWM-Signal.....	9		
5. What To Do In Case Of Breakdown? ...	28		



Current operating instructions are available via www.pfeiffer-vacuum.de/Info service.

1. Safety Precautions

Obey all relevant safety requirements (regulations and guidelines) and adopt suitable safety measures.

☞ Read and follow all the instructions in this manual.

☞ Inform yourself regarding:

- Hazards which can be caused by the pump;
- Hazards which can arise in your system;
- Hazards which can be caused by the medium being pumped.

Use the equipment for the intended use only (for generation of vacuum).

☞ Avoid exposing any part of the body to vacuum.

☞ Obey notes on correct vacuum and electrical connections, see section "Use and operation".

☞ Make sure that the individual components are only connected, combined and operated according to their design and as indicated in the instructions for use.

☞ Observe all safety and accident prevention regulations.

☞ Check regularly that all safety requirements are being complied with.

☞ Do not carry out any unauthorised conversions or modifications on the pump.

☞ Check that mains voltage and current conform with the equipment (see rating plate).

☞ Adopt suitable measures to prevent any danger arising from the formation of hot surfaces or electric sparks.

☞ When returning the pump to us please note the shipping instructions in Section 7.

Adopt suitable measures to prevent dangers arising from dangerous or explosive gases and ensure that the materials of the wetted parts are compatible, see section "Technical data".

☞ Adopt suitable measures to prevent the release of dangerous, explosive, corrosive or polluting fluids.

☞ Take adequate precautions to protect people from the effects of dangerous substances, wear appropriate safety-clothing.

☞ Obey applicable regulations when disposing of chemicals. Take into consideration that chemicals may be polluted.

Adopt suitable measures to prevent dangers arising from the formation of explosive fluids or explosive or flammable mixtures.

☞ Use inert gas for gas ballast if necessary.

☞ The user must take suitable precautions to prevent any formation of explosive mixtures in the expansion chamber. In case of a diaphragm crack, mechanically generated sparks, hot surfaces or static electricity may ignite these mixtures.

Modifications reserved

Due to the residual leak rate of the equipment, there may be an exchange of gas, albeit extremely slight, between the environment and the vacuum system.

- ☞ Adopt suitable measures to prevent contamination of the pumped substances or the environment.

Electronic equipment is never 100% fail-safe. This may lead to an indefinite status of the equipment. Provide protective measures against malfunction and failure.

- ☞ Stand still of the pump or operating a valve must not lead to a critical dangerous situation under any circumstances.

Ensure that in case of failure the pump and the vacuum system always will turn into a safe status.

- ☞ In case of diaphragm cracks or leaks in the manifold pumped substances might be re-released into the environment or into the pump housing.
- ☞ Obey especially notes on operation and use and maintenance.

Use only genuine spare parts and accessories.

- ☞ Otherwise safety and performance of the equipment as well as the electromagnetic compatibility of the equipment might be reduced.

Ensure that maintenance is done only by suitable trained and supervised technicians.

Ensure that the maintenance technician is familiar with the safety procedures which relate to the product processed by the vacuum system and that the equipment, if necessary, is appropriately decontaminated before starting maintenance.

Obey local and national safety regulations.

Before starting maintenance vent the system, isolate the pump and other components from the vacuum system and the electrical supply and allow sufficient cooling of the pump.

In order to comply with law (occupational, health and safety regulations, safety at work law and regulations for environmental protection) vacuum pumps, components and measuring instruments returned to the manufacturer can be repaired only when certain procedures (see section "Notes on return to the factory") are followed.

1.1. For Your Orientation

Instructions in the text

➔ Operating instructions: Here you have to do something!

Symbols used

The following symbols are used throughout in the illustrations:

- Ⓥ Vacuum flange
- Ⓛ Exhaust flange
- ⓐ Gas ballast valve
- ⚡ Power supply connection

Position numbers

Identical components and accessories parts have the same position numbers in all illustrations.

Pictogram Definitions



Danger of personal injury.



Danger of damage to the pump or system.



Danger of burns from touching hot parts.



Danger of an electric shock.




Important note.

2. Understanding The Pump

2.1. Main Features


MVP 020-3 AC

- 1 Intake connection, delivery version with swivelling screw-fitting G1/4".
- 2 Exhaust silencer
- 9 Handle
- 10 Interhead connection
- 11 Hollow screw
- 13 Mains connection with securing ring and main switch
- 14 Voltage selection switch



MVP 020-3 DC

- 1 Intake connection
- 2 Exhaust silencer
- 10 Interhead connection
- 11 Hollow screw
- 13 Power supply connection
- 16 Connection control voltage



Proper use

- The Diaphragm Pump MVP 020 may only be used for the purpose of generating vacuum.
- Do not pump corrosive or explosive gases.
- Do not pump liquids.
- Do not operate the pump in locations where there is an explosion hazard.
- Accessories other than those named in this manual may not be used without the agreement of PFEIFFER.
- Do not use the connecting line between the two membrane heads as a handle.
- The Diaphragm Pump MVP 020 may not be used for the purpose of generating pressure.

2.2. Differences Between The Pump Types

Merkmal	MVP 020-3 DC	MVP 020-3 AC
Power supply	24V/DC \pm 10%	180 ... 254V; 50/60Hz 90 ... 126V; 50/60Hz
Voltage connection	power supply cable	via mains connection socket with securing ring and switch ¹⁾
Variable speed function	via control voltage ²⁾	no
Vacuum side	Swivelling screw-fitting (G1/8") at the vacuum side of the pump, 1m hose 8mm (inside dia.) / 10mm (outside dia.) with swivelling screw-fitting (G 1/4") at the other end for connection to PFEIFFER Turbopumpe	
Exhaust side	Silencer	

¹⁾ Mains power cable is not included in the delivery consignment, for individual ordering please see Section 10. Accessories.

²⁾ intermittent operation via 24 V= control voltage input (PWM signal) at turbo pump electronics TC 600/100 or customized variable speed operation (please see Section 3.4.2)

3. Installation

3.1. Setting Up The Pump And Location

Obey national safety regulations and safety requirements concerning the use of vacuum and electrical equipment.

- ➔ Remove all packing material, remove the product from its packing-box, remove the protective covers from the inlet and outlet ports and keep, inspect the equipment.
- ➔ If the equipment is damaged, notify the supplier and the carrier in writing within three days; state the item number of the product together with the order number and the supplier's invoice number. Retain all packing material for inspection.
- ➔ Do not use the equipment if it is damaged.
- ➔ If the equipment is not used immediately, replace the protective covers. Store the equipment in suitable conditions.
- ➔ Read and obey this manual before installing or operating the equipment.
- ➔ Transport the pump at the provided handles.
- ➔ If the equipment is brought from cold environment into a room for operation, allow the equipment to warm up (pay attention to water condensation on cold surfaces).
- ➔ Make sure ventilation is adequate if pump is installed in a housing or if ambient temperature is elevated.
- ➔ Provide a firm level platform for the equipment and check that the system to be evacuated is mechanically stable and that all fittings are secure.
Attention: Flexible elements tend to shrink when evacuated.

To the best of our knowledge the equipment is in compliance with the requirements of the applicable EC-directives and harmonized standards (see "Declaration of conformity") with regard to design, type and model, especially directive IEC 1010. This directive gives in detail conditions, under which the equipment can be operated safely (see also IP degree of protection).

- ➔ Adopt suitable measures in case of differences, e. g. using the equipment outdoors, installation in altitudes of more than 1000 m above mean sea level, conductive pollution or dewiness.
- ➔ Anchor the pump if it is to be erected in a stationary position.
- ➔ Anchoring is not necessary if the pump is not erected in a stationary position.
- ➔ Ambient temperature range + 12 ... +40 °C.
- ➔ Where rack installation is involved, ensure adequate ventilation.

3.2. Connecting The Vacuum Side

- ➔ Remove locking cap on intake connection.
- ➔ Make connection between the vacuum system and pump as short as possible.
- ➔ Connect pump with intake connection to the apparatus.
- ➔ Obey maximum permitted pressures and pressure differences, see section "Technical data". Do not operate the pump with overpressure at the inlet.
- ➔ If liquid - which would generate vapours - is present in the system to be evacuated, a condensate trap must be fitted upstream of the pump.

3.3. Connecting The Exhaust Side



Pressure can rise to dangerous levels in exhaust lines. Therefore, lay exhaust side lines without shut-off units. Do not connect the exhaust side with a closed system on account of the danger of bursting.

- In certain applications, exhaust gases and vapours can be very hot and represent a health and/or environment hazard.
- ➔ Lay lines from the pump sloping downwards so that condensate cannot run back into the pump, otherwise fit a separator.
 - ➔ Due to the high compression ratio of the pumps, pressure at the outlet port might be generated being higher than the max. permitted pressure compatible with the mechanical stability of the system.
 - ➔ Do not permit any uncontrolled pressurizing (e. g. make sure that the exhaust pipeline cannot become blocked). If you have an exhaust-isolation valve, make sure that you cannot operate the equipment with the valve closed. Risk of bursting!
 - ➔ Ensure that the system design does not allow the exhaust pipeline to become blocked.
 - ➔ Avoid overpressure of more than 0.2 bar in case inert gas is connected.
 - ➔ The diameter of the inlet and outlet pipeline should be at the least as large as the diameter of the pump connection pipelines.

3.4. Connecting To Mains Power

MVP 020-3 AC

The pump is driven by wide voltage AC motors with the following possible variants:

„230 V - range“: 180...254 V, 50/60 Hz

„115 V - range“: 90.. 126 V, 50/60 Hz



Power connections must comply with local regulations. Voltage and frequency information given on the voltage selector switch correspond to the mains voltage and frequency values. The pump may only be connected to mains current with earthed conductor.

3.4.1 Voltage Selector Switch Change-Over

The respective single phase mains voltage must be checked before each installation or re-location of the diaphragm pump.


Use an appropriate screwdriver on the diaphragm pump voltage selector switch to select the range which corresponds with the mains voltage provided.



Be sure to disconnect the pump from mains power before changing the voltage range.


Voltage Change-Over Switch 14 On The Terminal Box Cover

- A Setting range marking
- X Position "230", voltage range (180 ... 254V; 50/60Hz)
- Y Position "115", voltage range (90126V; 50/60Hz)



Prior to switching on the pump always check the voltage range which has been set in the pump terminal box.


Connection of MVP 020-3 AC with Relaisbox at TC 600 for intermittend operation




3.4.2 Supply Connections of the MVP 020-3 DC

MVP 020-3 DC

- 13 Power supply connection
- 16 Connection control voltage
- S Cover retaining screw



Connection of MVP 020-3 DC at TC 600 for intermittent operation



4. Operations

4.1. Important Information



Do not start pump if pressure difference between inlet and outlet port exceeds max. 1 bar.

Attempts to start pump at higher difference may cause blockade and damage of the motor. Check compatibility with max. pressure difference between inlet and outlet ports.


Interchanging the connections causes dangerous excess pressure levels.



When the pump is running, surfaces and motor casing become hot.

- The pump can be switched on and off at all times.
- The intake connection and the output are marked with **V** and **⊙** respectively.
- If the pump is subjected to condensates it should be allowed to run for a few minutes under atmospheric pressure before switching off.


4.2. Setup of Control Signal Input



In addition to the voltage input, the pump is equipped with a control signal input 16. In order to select the control signal input the DIP switch, sliding switch and trimmer on the control board under the side pump cover must be set.


For this, unscrew cover retaining screw S and carefully pull out the cable but only as far as is necessary.

Adjustments at sliding switch



Setting	
PWM:	External digital setting of the motor rotation speed via the PWM signal (works setting).
0 ... 10V:	External analog setting of the motor rotation speed via Voltage pre-selection

Adjustments at DIP switch



1	2	
on	on	Setting the motor rotation speed via the trimmer (programming mode).
on	off	Interlocking the trimmer pre-selection as previously selected (operating mode).
off	on	External digital setting of the motor rotation speed via the PWM signal (works setting).
off	off	External analog setting of the motor rotation speed via voltage pre-selection (0 ... 10V)

4.2.1 Intermittent Operations with PWM-Signal

To prolong the life of diaphragm pumps, intermittent operations can be selected with lesser gas throughputs of < 0.18 mbar l/s. This means that, dependent on the TMP power take-up, the backing pump will be switched on and off. TMP power take-up is dependent on the fore-vacuum pressure and gas throughput.

- By comparing the power take-up with an upper and a lower limit value, the relative switch-on duration with lesser gas throughputs can be reduced to approx. 1 to 60%
- To avoid too frequent switching on, the buffer volume in the fore-vacuum line should amount to ≥ 0.5 liter from approx. 0.018 mbar l/s.

Intermittent operation with turbo electronics TC 600 / 100

- ➔ Carry out adjustments at sliding switch and Dip switch for operation with PWM signal.
- ➔ Connect galvanic isolated PWM-signal to signal input 16.
 - 0 V ==> Pump „off“
 - 24 V ==> Pump „on“ (max. rotation speed)



For this operation mode there is no variable speed control possible.

Variable speed control

- ➔ Carry out adjustments at sliding switch and Dip switch for operation with PWM signal.
- ➔ Connect galvanic isolated PWM signal to signal input 16 for variable customized speed control.
 - (5V ... 24V); **absolutely necessary!**
 - Frequency range: >100 Hz, < 1,5 kHz.

Variable speed range:

PWM-signal	<25%	25%	25% ... 75%	>75%
Number of revolutions	0 RPM	350 RPM	Linear increasing	1600 UPM



Also see operating instructions „Adapter box „ PM 800 563 BN.

5. What To Do In The Case Of Breakdowns ?

Problem	Possible cause	Remedy
Pump fails to start or stops immediately.	<ul style="list-style-type: none"> ➔ Supply failure? ➔ Pressure in outlet pipeline too high? ➔ Motor overloaded? ➔ Dirty valves/diaphragms ➔ Wrong adjustment of the Voltage selection switch ➔ Ambient temperature < 12 °C ➔ On power relay version control voltage fault or relay defective. 	<ul style="list-style-type: none"> ☞ Check voltage supply. ☞ Remove blockade in line, open valve. ☞ Allow motor to cool, identify cause of failure. ☞ See maintenance in section 6. ☞ Check adjustment. ☞ Warm pump ☞ Check control voltage heck relay (see section 3.4. and 4.2.).
Pump does not achieve ultimate total pressure or normal pumping speed	<ul style="list-style-type: none"> ➔ Long narrow line? ➔ Pump has been exposed to condensate? ➔ Deposits have been formed inside the pump? ➔ hose connectors between pump are leaky ➔ Leak in system ➔ New diaphragms or valves ➔ Valves or diaphragm damaged? ➔ Outgasing substances or vapour generated in the process? ➔ Pump becomes to hot 	<ul style="list-style-type: none"> ☞ Use line with larger diameter, length as short as possible. ☞ Run pump at atmospheric pressure for a few minutes. ☞ Clean and inspect pump heads. ☞ Check hose connectors between pump heads for leaks. ☞ Repair leak ☞ A run-in period of several hours is required before the pump achieves its ultimate vacuum. ☞ Replace valves and/or diaphragms. ☞ Check process parameters. ☞ Reduce pump rotation speed, ensure enough cooling or reduce input pressure.
Pump too noisy.	<ul style="list-style-type: none"> ➔ Valves or diaphragm damaged? ➔ Atmospheric or high pressure at inlet port? ➔ Diaphragm clamping disc loose? ➔ None of above mentioned causes? 	<ul style="list-style-type: none"> ☞ Replace valves and/or diaphragms. ☞ Connect hose to pump outlet. ☞ Perform maintenance. ☞ Return the equipment to PFEIFFER service.
Pump seized.		<ul style="list-style-type: none"> ☞ Return the equipment to PFEIFFER service.

6. Maintenance

6.1. Precautionary Measures During Maintenance Work



Whenever working on the pump ensure the motor cannot get switched on. If necessary, remove pump from the system for inspection. Before dismantling allow the pump to cool down.

- ➔ Only dismantle the pump as far is necessary to effect repairs.
- ➔ Use only alcohol or similar cleaning agents for cleaning. Do not use solvents.

All bearings are encapsulated and are filled with long-life lubricant. Under normal operating conditions, the pump is maintenance free. The valves and the diaphragms are wear parts. If the rated ultimate vacuum is no longer achieved, the pump interior, the diaphragms and the valves must be cleaned and the diaphragms and valves must be checked for cracks or other damage.

Depending on individual cases it may be efficient to check and clean the pump heads on a regular basis. In case of normal wear the lifetime of the diaphragms and valves is > 10000 operating hours.



Prevent internal condensation, transfer of liquids or dust. The diaphragm and valves will be damaged, if liquids are pumped in significant amount.

6.2. Cleaning And Replacing Valves And Diaphragms

- ➔ Allow the pump to cool down before dismantling.
- ➔ Use open-ended wrench SW 14 to remove fitting 11 (hollow screw) at the pump head and remove together with connecting hose.



To not remove housing bearing flange 8.

- ➔ Remove two screws at the handle 9 and remove together with handle.
- ➔ Use hex key to remove six socket head screws 1.3 from pump head and remove upper housing (housing cover 1.1 and head cover 3.1).




Never remove parts by using a spiky or sharp-edged tool (e. g. screw driver), we recommend to use a rubber mallet or compressed air (to be blown carefully into port).

- ➔ Remove head cover 3.1 from housing cover I (1.1) and check valves 3. Note position of valves and remove. Replace valves if necessary.
 - Use petroleum ether or industrial solvent to remove deposits. Do not inhale.
 - Check diaphragm for damage and replace if necessary.

Replacing the diaphragm:

- ➔ Lift diaphragm 5 carefully.
 - Apply pressure to the clamping disc 4 beside the diaphragm to bring connecting rod 7 into upper turning point position if necessary.
 - Never use a spiky or sharp-edged tool to lift the diaphragm.




- ➔ Use diaphragm key to grip under the diaphragm to the diaphragm support disc 6.
- ➔ Apply pressure to the diaphragm clamping disc to bring the diaphragm into lower turning point position. Press diaphragm key against diaphragm clamping disc and remove diaphragm support disc with diaphragm.
 - If the old diaphragm is difficult to separate from the support disc, immerse assembly in naphtha or petroleum ether. Do not inhale!
 - Check for washers under clamping disc. Do not mix the washers from the different heads. Make sure that the original number is reassembled at the individual pump head.
- ➔ Position new diaphragm between diaphragm clamping disc with square head screw and diaphragm support disc.



Position diaphragm with white PTFE side to diaphragm clamping disc (to pump chamber).


Dismantling / Assembling pump heads

- 1.1 Housing cover I
- 1.3 Socket head screws
- 2.1 Housing cover II
- 3 Valves
- 3.1 Head cover
- 4 Clamping disc with square head screw
- 5 Diaphragm
- 6 Diaphragm support disc
- 7 Disc
- 8 Housing bearing flange
- 9 Handle
- 10 Interhead connection
- 11 Fitting (Hollow screw)
- 12 USIT-Ring



- ➔ Lift diaphragm at the side and position carefully together with diaphragm clamping disc and diaphragm support disc in the diaphragm key.
 - Avoid damage of the diaphragm: Do not crack diaphragm in a way that light lines at the diaphragm upper side occur.
- ➔ Check for washers under clamping disc. Do not mix the washers from the different heads. Make sure that the original number is reassembled at the individual pump head.
 - Smaller number of washers: The pump will not attain final vacuum. More washers: Clamping disc will hit head cover; noise or even blockage of the pump.
- ➔ After assembling all parts rotate pump 180° and dismantle lower housing cover II (2.1) in the same manner.

Assembling diaphragm clamping disc, diaphragm and diaphragm support disc to connecting rod.





Assembling pump heads:

- ➔ Make sure that the square head screw of the diaphragm clamping 4 disc is correctly seated in the guide hole of the diaphragm support disc 6.
- ➔ Assemble diaphragm clamping disc, diaphragm and diaphragm support disc to connecting rod.
 - Position washers if available between diaphragm support disc and rod 7.
- ➔ Bring diaphragm into a position in which diaphragm is in contact with housing and centred with respect to bore.
- ➔ Assemble head cover 3.1 and valves 3.
 - Check for correct position (see fig. below).



Obey position and orientation of the head covers and the valves definitely.



Assembling fittings:

- ➔ Use open ended wrench to reconnect fittings with connection hose to pump heads.
- Fix the ring nut when tighten the hollow bolt.



If the pump does not achieve the ultimate pressure:

In case the diaphragms and valves have been replaced, a run-in period of several hours is required before the pump achieves its ultimate vacuum.

If all pump heads achieve a vacuum below 90 mbar but pump does not achieve the ultimate total pressure:

- ➔ Check hose connectors between pump heads and manifolds for leaks. If necessary recheck pump chamber.

- ➔ Position housing cover I (1.1).
 - Move housing cover slightly to make sure that the head covers are correctly positioned.
 - Screw in six socket head screws 1.3 fixing housing cover crosswise first slightly, then tighten.



Do not tighten until housing cover is in contact with housing, max. torque 6 Nm.

- ➔ Assemble handle 9 with screws and tighten.
 - Check for correct position of the handle over the centre of gravity of the pump. The handle is in correct position if the end of the handle is positioned over the end of the housing cover.

7. Service

Please note:

Repair orders are carried out according to our general conditions of sale and supply. If repairs are necessary, please send the unit to your nearest PFEIFFER Service Center.



Decontaminate units before returning or possible disposal. Do not return any units which are radioactively, microbiologically or biologically contaminated.

Before returning:

- ➔ Please attach a clearly visible notice "Free of harmful substances" (both on the unit and also on the delivery note and any accompanying letters).

"Harmful substances" are defined in European Union Countries as: "materials and preparations in accordance with the EU Specification dated 18 September 1979, Article 2" and in the U.S.A. as

"materials in accordance with the Code of Federal Regulations (CFR) 49 Part 173.240 Definition and Preparation". We will carry out the decontamination and invoice this work to you if you have not attached this note. This also applies where the operator does not have the facilities to carry out the decontamination work.

Units which are contaminated radioactively, microbiologically or biologically cannot be accepted as a matter of principle.

Fill Out The Contamination Declaration

- ➔ In every case the "Contamination Declaration" must be completed diligently and truthfully.
- ➔ A copy of the completed declaration must accompany the unit; any additional copies must be sent to your local PFEIFFER Service Center.

If there are any questions concerning contamination, please get in touch with your local PFEIFFER representatives.

Returning Contaminated Units

If contaminated units have to be returned for maintenance or repair, the following instructions concerning shipping must be followed:

- ➔ Neutralise the pump by flushing with nitrogen or dry air.
- ➔ Seal all openings to the air.
- ➔ Seal pump or unit in suitable protective foil.
- ➔ Ship units only in appropriate transport containers.

Contact Addresses And Service Hotline

Contact addresses and telephone numbers can be found on the back cover of these operating instructions.

8. Technical Data




Size Unit	Unit	MVP 020-3 AC	MVP 020-3 DC
Connections			
Intake side ¹⁾		G 1/8" (at the pump)	G 1/8" (at the pump)
Option:	DN 16	small flange ISO-KF	small flange ISO-KF
Pressure side		G 1/8" with silencer	G 1/8" with silencer
Nominal volume flow rate at 1000 mbar			
50 Hz	m ³ /h	1	
60 Hz	m ³ /h	1,2	
24V/DC	m ³ /h		1
Nominal rotation speed at 50/60 Hz	min ⁻¹	1500 / 1800	
Max. rotation speed	min ⁻¹	—	1500
Final pressure	mbar	≤ 2	≤ 2
Permissible exhaust pressure without final pressure change	mbar	1100	1100
Leak rate	mbar l/s	≤ 1·10 ⁻¹	≤ 1·10 ⁻¹
Max. erection height	m	approx. 2000	approx. 2000
Max. permissible operating temperature	°C	+12 ... +40	+12 ... +40
Noise level	dB(A)	ca. 48	ca. 48
Motor power supply		Dual voltage	Variable speed drive
	V	90 ... 126 V/AC	24 V/DC (+/- 10%)
	V	180 ... 254 V/AC	
Motor power, max.	W	80 (delivered power)	64 (delivered power)
Motor current draw	A	1,7 (for 100 ... 120 V)	3,5 (at 1000 mbar)
	A	0,85 (for 200 ... 240 V)	0,9 (at final pressure)
Motor protection		IP 54	IP 20
Weight, approx.	kg	6,5	4,1

¹⁾ included with hose d1 (inside dia.) / d2 (outside dia.) = 8/10mm with G1/4" connection or DN16 ISO-KF

8.1. Dimensions

MVP 020-3 AC



- 1 Inlet with hose connection
- 2 Silencer
- 10 Interhead connection
- 11 Hollow screw
- 13 Mains connection with main switch



PK217mAC

MVP 020-3 DC

- 1 Inlet with hose connection
- 2 Outlet with Silencer
- 9 Handle
- 10 Interhead connection
- 11 Hollow screw
- 13 Power supply connection
- 16 Connection for control voltage



PK217mDC


8.2. Substances Which Come Into Contact With The Medium

Pump components	Substances in contact with the media
Housing cover	Aluminium
Head cover	Aluminium
Diaphragm clamping disc	Aluminium
In- outlet valves	FPM
Diaphragm	PTFE coated NBR
Intake connection (Hose nipple)	Aluminium, anodised
Exhaust silencer	PA / PE / Aluminium
Hose	PA
Fittings	Aluminium, anodised

9. Spare Parts

Pos.	Description	Pieces MVP 020-3 AC	Pieces MVP 020-3 DC	Size	Number (for 1 piece)	Comments
	MVP 020-3 AC and MVP 020-3 DC Set of wearing parts	1	1		PK 050 119-T	including 4 diaphragm, 8 valves and diaphragm key
	Diaphragm key	1	1		P 0995 941	
2	Silencer	1	1		P 0995 942	
11	Fitting (Hollow screw)	1 of 2	1 of 2	G 1/8"/M6	P 0995 943	
12	USIT ring	1 of 8	1 of 7	G1/8"	P 0995 944	

When ordering accessories and spare parts please be sure to state the full part number. When ordering spare parts please state additionally the unit type and unit number (see rating plate). Please use this list as an order form (by taking a copy).



10. Accessories

MVP 020-3 AC

Pos.	Description	Pieces	Size	Number	Comments / Operating instructions	Order Quantity
	Mains cable for turbopumps with TC 600 and relay box or individual wiring (without plug)	1	3,0 m	PK 050 111		
	Mains cable 230 V with schuko plug, EURO Counter plug CEE 22	1	2,0 m	PK 050 109		
	Mains cable 115 V, UL EURO Counter plug CEE 22	1	2,0 m	PK 050 110		
	Small flange for intake or outlet side	1	DN 16 ISO-KF	PK 050 108-T	(for input or output optional)	
	Relay box for connection to TC 600	1		PM 041 937 AT		

MVP 020-3 DC

Pos.	Description	Pieces	Size	Number	Comments / Operating instructions	Order Quantity
	Small flange for intake or outlet side	1	DN 16 ISO-KF	PK 050 108 -T	for input or output optional	
	TPS 150, 24 V/DC power unit	1	150 VA	PM 051 461 -T	PM 800 521 BN	
	Power supply cable TPS 150 / Diaphragm pump (at pos. 13)	1	3 m	PM 051 103 -T	optional shielded	
	Power supply cable TPS 150 / Diaphragm pump (at pos. 13)	1	5 m	PM 051 104 -T	optional shielded	
	Connecting cable TC 600 / Diaphragm for variable speed control (at pos. 16)	1	0,5 m	PM 041 959 -X		
	Connector assembly for power supply	1		P 0920 635 E	counter part to pos. 13	
	Connector assembly variable speed control	1		P 0992 287	counter part to pos. 16	

Declaration of Contamination of Vacuum Equipment and Components

The repair and/or service of vacuum components will only be carried out if a correctly completed declaration has been submitted. Non-completion will result in delay.

The manufacturer could refuse to accept any equipment without a declaration.

This declaration can only be completed and signed by authorised and qualified staff:

<p>1. Description of component:</p> <ul style="list-style-type: none"> - Equipment type/model: _____ - Code No.: _____ - Serial No.: _____ - Invoice No.: _____ - Delivery Date: _____ 	<p>2. Reason for return:</p> <p>_____</p> <p>_____</p> <p>_____</p> <p>_____</p>
<p>3. Equipment condition</p> <ul style="list-style-type: none"> - Has the equipment been used? yes <input type="checkbox"/> no <input type="checkbox"/> - What type of pump oil was used? _____ - Is the equipment free from potentially harmful substances? yes <input type="checkbox"/> (go to section 5) no <input type="checkbox"/> (go to section 4) 	<p>4. Process related contamination of equipment</p> <ul style="list-style-type: none"> - toxic yes <input type="checkbox"/> no <input type="checkbox"/> - corrosive yes <input type="checkbox"/> no <input type="checkbox"/> - microbiological hazard*) yes <input type="checkbox"/> no <input type="checkbox"/> - explosive*) yes <input type="checkbox"/> no <input type="checkbox"/> - radioactive*) yes <input type="checkbox"/> no <input type="checkbox"/> - other harmful substances yes <input type="checkbox"/> no <input type="checkbox"/>

*) We will not accept delivery of any equipment that has been radioactively or microbiologically contaminated without written evidence of decontamination!

Please list all substances, gases and by-products which may have come into contact with the equipment:

Tradename Product name Manufacturer	Chemical name (or Symbol)	Danger class	Precautions associated with substance	Action if spillage or human contact
1.				
2.				
3.				
4.				
5.				

5. Legally Binding Declaration

I hereby declare that the information supplied on this form is complete and accurate. The despatch of equipment will be in accordance with the appropriate regulations covering Packaging, Transportation and Labelling of Dangerous Substances.

Name of Organisation: _____

Address: _____ Post code: _____

Tel.: _____

Fax: _____ Telex: _____

Name: _____

Job title: _____

Date: _____ Company stamp: _____

Legally binding signature: _____



Konformitätserklärung
Declaration of Conformity



im Sinne folgender EU-Richtlinien:
pursuant to the following EU directives:

- **Maschinen/Machinery 98/37/EG**
- **Elektromagnetische Verträglichkeit/Electromagnetic Compatibility 89/336/EWG**
- **Niederspannung/Low Voltage 73/23/EWG**

Hiermit erklären wir, daß das unten aufgeführte Produkt den Bestimmungen der EU-Maschinenrichtlinie 98/97/EG - Anhang IIA, der EU-Richtlinie über elektromagnetische Verträglichkeit 89/336/EWG und der EU-Niederspannungsrichtlinie 73/23/EWG entspricht.

We hereby certify that the product specified below is in accordance with the provision of EU Machinery Directive 98/97/EEC - Annex II A, EU Electromagnetic Compatibility Directive 89/336/EEC and EU Low Voltage Directive 73/23/EEC.

Produkt/Product:

MVP 020-3 AC
MVP 020-3 DC

Angewendete Richtlinien, harmonisierte Normen und angewendete, nationale Normen in Sprachen und Spezifikationen:

Guidelines, harmonised standards, national standards in languages and specifications which have been applied:

EN 292-1,	EN 292-2
EN 60 204-1	EN 60 335-1
EN 55 014	EN 50 081-1
EN 50 082-1	EN 60 555-2,
EN 60 555-3	EN 1012-2

Unterschrift/Signature:



Pfeiffer-Vacuum GmbH
Berliner Strasse 43
35614 Asslar
Germany

(W. Dondorf)
Geschäftsführer
Managing Director

Adressen • Addresses

Argentina

ARO S.A., Av. Belgrano 369,
1092 Buenos Aires, telephone +54 / 11 4331 5766,
telex +54 / 11 4331 3572

Australia

Sciteck Australia Pty. Ltd., Suite 1B,
10-18 Cliff Street, Milsons Point, NSW 2061,
telephone +61 / 2 9954 1925, telex +61 / 2 9954 1939

Austria

Pfeiffer Vacuum Austria GmbH
Diefenbachgasse 35, A-1150 Wien,
telephone +43 / 1 8941 704, telex +43 / 1 8941 707
Service Hotline: +43 / 1 8941704

Branch Office, Czech Republic

Pfeiffer Vacuum Austria GmbH, Branch Prague
Zvonarska 885
CZ-156 00 Praha 5
telephone + 420/2 900 42981, telex + 420/2 579 23014

Belgium / Luxemburg

Pfeiffer Vacuum Belgium N.V./S.A.
Luxemburgstraat 5, B-9140 Temse
telephone +32 / 3 710 5920, telex +32 / 3 710 5929
Service Hotline: +32 / 3 710 5922

Brazil

Elmi Tec
Assistencia Técnica e Representação S/C Ltda.
Rua Bernadino de Comos, 551-Brooklin
CEP 04620-002 São Paulo, SP - Brasil
telephone +55 / 11 5532 0740, telex +55 / 11 5535 3598

Chile

BERMAT S.A., Coyancura 2283, Oficina 601
Providencia, P.O. Box 9781, Santiago
telephone +56 / 2 231 8877, telex +56 / 2 231 4294

Colombia

Arotec Colombiana S.A., Carrera 16 No. 36-89
P.O. Box 050 862, Santafé de Bogotá / D.C.
telephone +57 / 1 288 7799, telex +57 / 1 285 3604

Denmark

Pfeiffer Vacuum Scandinavia AB, Vesterengen 2,
DK-2630 Taastrup,
telephone +45 / 43 52 38 00, telex +45 / 43 52 38 50

France

Pfeiffer Vacuum France SAS
45, rue Senouque, BP 139
F-78531 BUC Cedex
telephone +33 / (0)1 30 83 04 00,
telex +33 / (0)1 30 83 04 04

Germany

Pfeiffer Vacuum GmbH,
Berliner Strasse 43, D-35614 Asslar
telephone +49 / 6441 802 400, telex +49 / 6441 802 399
Service Hotline: +49 / 6441 802 333

Great Britain

Pfeiffer Vacuum Ltd.
2-4 Cromwell Business Centre
Howard Way, Interchange Park
Newport Pagnell, MK16 9QS, United Kingdom
telephone +44 / 1 908 500615, telex +44 / 1 908 500616

Greece

Analytical Instruments S.A., 1 Mantzarou St.,
GR-15451 Athens,
telephone +30 / 10 674 8973-7, telex +30 / 10 674 8978

Hong Kong

Pfeiffer Vacuum Asia Ltd.
Units 06-07, 17/F, Workingfield Commercial Building,
408-412 Jaffe Road, Hong Kong
telephone +852 2575 6688, telex +852 2575 6993

India

Pfeiffer Vacuum India Ltd.
25-E Nicholson Road, Tarbunde
Secunderabad 500 009,
telephone +91 / 40 775 0014, telex +91 / 40 775 7774

Israel

ODEM Scientific Applications Ltd.
9 Hamazmera St., P.O.B. 2001 Nes Ziona
telephone +972 8 938 0333, telex +972 8 938 0334

Italy

Pfeiffer Vacuum Italia S.p.a.
Via San Martino, 44 I-20017 RHO (Milano)
telephone +39 / 2 93 99 051, telex +39 / 2 93 99 05 33

Japan

Hakuto Co. Ltd., C.P.O. Box 25,
Vacuum Scientific Instruments Division
C.P.O. Box 25, Tokyo 100-91
telephone +81 / 3 32 258 910, telex +81 / 3 32 259 011

Korea

Pfeiffer Vacuum Korea Ltd.,
703 Ho, 853-1, Hankuk Mulru, Dongchonri, Suzi-Eup,
449-843 Yong-in City, Kyungkido
telephone +82 / 31 266 0741, telex +82 / 31 266 0747

Netherlands

Pfeiffer Vacuum Nederland BV
Veldzigt 30a, NL-3454 PW De Meern,
telephone +31 / 30 6666050, telex +31 / 30 6662794

Peru

Ing. E. Brammert s.r.l., José Pardo 182,
Apartado 173, PE-18 Miraflores,
telephone +51 / 1 445 8178, telex +51 / 1 445-1931

Poland

Softrade Sp.z.o.o, ul. Grunwaldzka 391,
PL-60-173 Poznan, telephone +48 / 61 8677 168,
telex +48 / 61 8677 111

Portugal

Unilaser Lda, Taguspark
Núcleo Central, sala n° 268,
Estrada Cacém Porto Salvo, P-2780 Oeiras
telephone +351 / 1 421 7733, telex +351 / 1 421 7744

Singapore

APP Systems Services Pte Ltd, 11, Toh Guan Road East,
#03-01 APP Enterprise Building, Singapore 608603,
telephone +65 / 6425 6611, telex +65 / 6560 6616

Spain

Tecnovac
Tecnología de Vacío S.L.,
Sector Literatos, 38 - Local 1
ES-28760 Tres Cantos (Madrid)
telephone +34 / 91 804 11 34, telex +34 / 91 804 30 91

Sweden

Pfeiffer Vacuum Scandinavia AB
Johanneslundsvägen 3
SE-194 61 Ulplands Väsby
telephone +46 / 8 590 748 10, telex +46 / 8 590 748 88

Switzerland

Pfeiffer Vacuum Schweiz S.A.
Förlibuckstraße 30, CH-8005 Zürich
telephone +41 / 1 444 2255, telex +41 / 1 444 2266

South Africa

Labotec Pty Ltd., P.O. Box 6553,
Halfway House
1685 Midrand
telephone +27 / 11 315 5434, telex +27 / 11 315 5882

Taiwan

HAKUTO Taiwan Ltd. Hsinchu office No. 103,
Hsien Chen 11th Street, Chupei,
HsinChu County, Taiwan, R.O.C.
(zip/postal code: 302)
telephone +886 / 3 554 1020, telex +886 / 3 554 0867

Thailand

Hakuto (Thailand) Ltd.
18th Floor, Chokchai Int'l Bldg.
690 Sukhumvit Road
Klongton, Klongtoey
Bangkok 10110
telephone +662 / 259 6244, telex +662 / 259 6243

U.S.A.

Pfeiffer Vacuum, Inc.
24 Trafalgar Square
Nashua, NH 03063-1988
USA
telephone +1 / 603 578 6500, telex +1 / 603 578 6550

Venezuela

Secotec S.A., Apartado 3452, Caracas 1010-A,
telephone +58 / 212 573 8687, telex +58 / 212 573 1932

Other countries

AVI - Applied Vacuum Industries GmbH
Leginglenstrasse 17A; CH-7320 Sargans
Switzerland
telephone +41 / 81 710 03 80
telex +41 / 81 710 03 81

Scope of represented countries

Armenia, Azerbaijan, Bangladesh, Belarus, Bulgaria, Cambodia, Estonia, Georgia, Kazakhstan, Kingdom of Nepal, Kirghizia, Latvia, Lithuania, Maldives, Philippines, P.R. China, Rumania, Russia, Tajikistan, Turkmenistan, Ukraine, Uzbekistan, Vietnam

A.E.M.S.

Advanced Equipment Materials and Systems
P.O. Box 25
Föhrenweg 18
FL-9496 Balzers
telephone +423 / 380 0550
telex +423 / 380 0551

Scope of represented countries

Bahrain, Egypt, Iraq, Iran, Jordan, Kuwait, Lebanon, Lybia, Oman, Pakistan, Saudi-Arabia, Sudan, Syria, Turkey, United Arab Emirates, Yemen

Zentrale/Headquarters

Pfeiffer Vacuum GmbH

Berliner Str. 43
D-35614 Asslar

Telefon 06441/802-0
Telefax 06441/802-202
Hotline 06441/802-333
www.pfeiffer-vacuum.de

PFEIFFER  **VACUUM**