



**Edwards Vacuum E1M40 Maintenance Kit, 34401814 – Parts List**

<b>DESCRIPTION</b>	<b>PART NO.</b>	<b>QTY</b>
Filter Seal	E01403030	1
Dowty Seal	E02104001	2
Dowty Seal	E02104002	1
Dowty Seal	E02104008	1
Dowty Seal	E02104014	1
Viton Shaft Seal	E02109064	1
Viton Shaft Seal	E02109094	2
O-Ring	E02120027	1
O-Ring	E02120031	1
O-Ring	E02120057	1
O-Ring	E02120082	1
O-Ring	E02120097	1
O-Ring	E02124119	1
O-Ring	E02125011	1
O-Ring	E02125020	1
O-Ring	E02125044	2
O-Ring	E02125115	2
O-Ring	E02125116	5
O-Ring	E02126011	1
Ballast Piston	E19201007	1
1 <sup>st</sup> Stage Vane	E20402099G	2
Oil Pump Vane	E20402418G	2
Bearing	E20404011	2
Coupling	E21071033	1
Waved Washer	E218990201	1
Oil Filter	E22304041	1
Inlet Filter	E22305035	1
Ballast Filter	E22305041	2
Oil Filter	E22305050	1
C-Clip	E22426004	1



**Edwards Vacuum E1M40 Maintenance Kit, 34401814 – Parts List (cont.)**

Gas Ballast Valve	E25904601	1
Sight Glass Seal	E26501012	1
Spring	E27102013	1
Spring	E27102024	1
Rubber Seal	E27159415	1
Gasket	E27109428	1
Exhaust Valve	E27109514	1
Exhaust Valve	E27109515	1
Oil Case Gasket	E27109629	1
Valve Spacer	E27804004	4
Sight Glass	E29201006	1

**A & J Vacuum Services, Inc.**

790 Bloomfield Ave, Suite B3

Clifton NJ 07012 USA

973-249-0854