



Edwards Vacuum E2M8 Maintenance Kit, 36201800 – Parts List

DESCRIPTION	PART NO.	QTY
Drain Plug	E00714012	1
Filter Seal	E00906042	1
Vane Spring	E00906077	4
Dowty Seal	E02104001	1
Viton Shaft Seal	E02109066	1
Viton Shaft Seal	E02109067	1
O-Ring	E02120004	3
O-Ring	E02120028	2
O-Ring	E02120041	1
O-Ring	E02120077	2
O-Ring	E02124086	1
O-Ring	E02125013	1
O-Ring	E02125026	3
O-Ring	E02126116	2
Ballast Valve	E11301045	1
2 nd Stage Vane	E20402079G	2
1 st Stage Vane	E20402085G	2
Oil Pump Vane	E20402158G	1
Steel Ball	E20414003	1
Waved Washer	E218990201	1
Felt Pad	E22302013	1
Oil Filter	E22305003	1
Key	E24301010	1
Ballast Filter	E25907200	1
Button Valve	E26501017	1
Ballast Spring	E27102010	1



Edwards Vacuum E2M8 Maintenance Kit, 36201800 – Parts List (cont.)

Valve Spring LV	E27102016	1
Valve Spring HV	E27102029	1
Distributor Spring	E27102032	1
Distributor Rubber	E27159414	1
Valve Rubber	E27159417	1
Distributor Rubber	E27159440	1
Oil Case Gasket	E27159616	1
Spring Pin	E29203003	4

A & J Vacuum Services, Inc.

790 Bloomfield Ave, Suite B3

Clifton NJ 07012 USA

973-249-0854