



## DPG 202

USB driver installation

# Installation Instructions

# 1 Installation of the USB driver

## 1.1 System requirements

Prior to installing the software, please make sure, that the computer offers the following minimal system features.

### Software (with latest Service Pack)

- Windows XP (requires administrative support)
- Windows Vista (requires administrative support)
- Windows 7 (requires administrative support)
- Windows 8 (requires administrative support)

### Driver downloads

- The USB driver is available at [www.pfeiffer-vacuum.de](http://www.pfeiffer-vacuum.de).

## 1.2 Version Windows XP




### Observe the correct sequence for the installation!

Ensure that the driver software is installed on the computer, before connecting the DPG 202 to the USB interface.

- Start Windows. If it is already running, close all applications.
- Start the installation by executing the file **dpinst\_x86** (32 bit system).
- On the screen appears:



- Click "**Next**" to continue the installation.




All the necessary driver files will now be installed.




- ➔ When the installation finished, click "**Finish**" to close the wizard.
- ➔ Connect unit interface to the PC's USB interface.



- Do not confirm Windows Update - select **"No, not this time"**.
- Click **"Next"** to continue the installation.



- Click **"Next"** to continue the installation.



→ Wait until the interface is initialized.




→ When the installation finished, click "**Finish**" to close the wizard.

→ Restart the computer.

The DPG 202 can now be used at this USB port.

### 1.3 Version Windows 7 and 8

- Start Windows. If it is already running, close all applications.
- Start the installation by executing the file **dpinst\_x86** (32 bit system).
- Start the installation by executing the file **dpinst\_x64** (64 bit system).
- On the screen appears:



- Click "Ja" to continue the installation.



- Click "Next" to continue the installation.



→ Click "Installieren" to continue the installation.



All the necessary driver files will now be installed.



- When the installation finished, click "**Finish**" to close the wizard.
- Connect unit interface to the PC's USB interface.

**Vacuum solutions  
from a single source**

Pfeiffer Vacuum stands for innovative and custom vacuum solutions worldwide, technological perfection, competent advice and reliable service.

**Complete range  
of products**

From a single component to complex systems: We are the only supplier of vacuum technology that provides a complete product portfolio.

**Competence in  
theory and practice**

Benefit from our know-how and our portfolio of training opportunities! We can support you with your plant layout and provide first-class on-site-service worldwide.

**Are you looking for a  
perfect vacuum solution?  
Please contact us**

**Pfeiffer Vacuum GmbH**  
Headquarters • Germany  
T +49 6441 802-0  
info@pfeiffer-vacuum.de